

## CableClam Installation Instructions

PN 1007

1. Run cable through center hole of gasket.
2. Fit cable into deck ring groove.
3. Fasten deck ring and gasket to the surface by tightening each screw a few turns at a time. Do not over-tighten screws.

